

# **Procedure Card**



Study the Package Insert thoroughly before using this Procedure Card. This is not a complete Package Insert.

#### **Kit Contents**



Buffer

**Tubes** 

Process Reaction



Reaction Tubes



Negative Positive Control Control


### **Equipment**



95°C Lysis Block



Solana Instrument




Workflow Tray



Transfer Rack


# **Assay Procedure - Heat Lysis**





Setup the Workflow Tray with patient samples, Process Buffer Tubes, and Reaction Tubes.

2



Specimen in transport media.



VORTEX 5 seconds



n Add 50 µ lia. patient sa to a Proc



Add 50 µL of a patient sample to a Process Buffer Tube.



VORTEX 5 seconds



Heat for 5 minutes at 95°C.







Allow the heated Process Buffer Tubes to return to Room Temperature prior to addition to the Reaction Tubes.

# **Amplification and Detection**



Transfer 50 µL to each Reaction Tube.



Lower the Reaction Tubes into Solana.





Rehydrate by pipetting up and down a minimum of 5 times.





Release the Reaction Tubes from the Transfer Rack by pulling the Transfer Rack toward your body.





Close lid tightly and proceed to next step.





Close the lid and select appropriate assay protocol. Run complete in 25 minutes.



Use the Transfer Rack to lift Reaction Tubes from the Workflow Tray.



Tes	t results				06. Aug 2020, 21:41
1	SARS-CoV-2 Positiv	5	SARS-CoV-2 Positive 5555	9	empty
2	SARS-CoV-2 Positiv 2222	6	SARS-CoV-2 Negative 6666	10	empty
3	SARS-CoV-2 Negativ 3333	7	empty	11	empty
4	SARS-CoV-2 Positiv 4444	8	empty	12	empty
=	<b>△</b>				

Review results.